

WARNING:

Before installing or operating this TrafficFix 10,000 TMA, read the installation and maintenance manual.

1. Check that the area around the TMA is clear when lowering and raising the TMA.
2. In the down position, the TMA must be $305 \text{ mm} \pm 25$ ($12'' \pm 1''$) above the ground to perform correctly.
3. Check that all 1" pins are properly secured with retainer safety pins and that the bracket mounting bolts are secure.
4. The correct travel position is the raised position – check for wide turns because of the extended rear truck over hang.
5. After a vehicle impact with this TMA, the width will be wider than 96" – either remove the damaged cartridge by removing the four 1" pins or use a wide load shadow vehicle while transporting a crushed cartridge.
6. Provide proper maintenance by periodically checking the hydraulic pump fluid level, checking for secure bolts on the module lights, and the jack wheels, clean the rods on the hydraulic cylinders and check for operation of all light bulbs.
7. Check that the four jacks are all secured in the up position before driving the truck.
8. Check that the four energy-absorbing cartridges are in place if the system has been repaired. For proper crash performance, all four cartridges must be installed.

WARNING:

In the event that the operator of this TMA system is not sure of proper installation, operation, or maintenance of this TMA system, call customer service (949) 361-5663.